TOWABLE SERVICE PACKAGES

CALL US TO SCHEDULE TODAY!

We have a service package for every RV.

Beginning with the Basic Package that provides basic maintance and progressing to the ultimate package which offers a more robust annual maintance solution.

www.WhiteSandsRV.com 251-986-3330



ULTIMATE

Visual Inspection

- Outside lights Includes repairing 2 lights
- · Roof membrane condition & sealant
- Body & window sealant
- Awnings
- Shackles & springs
- · Check tires & ajust tire pressure to specifications
- · Inspect breakaway safety switch
- Preform amp draw on brakes

Lubricate the Following:

- Antenna gears
- · Locks & latches
- Entry steps

Service the Follwing:

- Battery
- Slides & jacks
- Water heater
- Refrigerator
- Air conditioner
- Clean & Lube coupler
- Flush & sanitize fresh water system

Axle Service and Inspection of:

- Check brakes
- Replace inner seals on axles
- Check bearings and repack

Roof Reseal:

- Scrape off loose sealant
- Reseal with new sealant

FREE

- · Clean & condition roof(add protectant)
 - Quick Exterior wash (\$350 VALUE)

PREMIUM

Visual Inspection

- Outside lights Includes repairing 2 lights
- · Roof membrane condition & sealant
- Body & window sealant
- Awnings
- Shackles & springs
- Check tires & ajust tire pressure to specifications
- · Inspect breakaway safety switch
- Preform amp draw on brakes

Lubricate the Following:

- Antenna gears
- Locks & latches
- Entry steps

Service the Follwing:

- Battery
- Slides & jacks
- Water heater
- Refrigerator
- Air conditioner
- Clean & Lube coupler
- · Flush & sanitize fresh water system

Axle Service and Inspection of:

- Check brakes
- · Replace inner seals on axles
- Check bearings and repack

FREE

- Roof spot seal
- Inspect roof
- Reseal needed areas (\$120 VALUE)

BASIC

Visual Inspection

- Outside lights Includes repairing 2 lights
- Roof membrane condition & sealant
- Body & window sealant
- Awnings
- Shackles & springs
- Check tires & ajust tire pressure to specifications
- Inspect breakaway safety switch
- Preform amp draw on brakes

Lubricate the Following:

- Antenna gears
- Locks & latches
- Entry steps

Service the Follwing:

- Battery
- Slides & jacks
- Water heater
- Refrigerator
- Air conditioner
- Clean & Lube coupler
- Flush & sanitize fresh water system